




**Part No. ALL10660**  
**ALL10662**


## Set Up Plates

Set-up plates are used for squaring and stringing chassis to ensure accurate chassis set-up by eliminating wheel and tire differences. Plates can also be used when setting bump steer or checking axle tubes for straightness. Sold each.

Part No.	Description
ALL10660	5x5, 7" x 28"
ALL10662	Wide 5, 12" x 28"



ALL10660



ALL10662