



SWITCH PANEL P/N 74190

PARTS

1 – Switch Panel Box	1 – Momentary Switch	2 – DZUS Buttons
1 – Back Panel	5 – ON/OFF Switches	27 – Connectors
2 – Plastic Grommets	5 – Circuit Breakers	1 – Label Sheet

INSTALLATION INSTRUCTIONS

1. Disconnect battery before beginning installation.
2. Prepare a location on the roll bar to weld the Back Panel. Leave enough room for the Switch Panel Box.
3. After you have finished preparing the mounting area, fit the Back Panel on the roll bar and weld it in place from the inside of the panel. (See diagram on back)
4. Insert the two Plastic Grommets into the holes of the Back Panel. These holes will be used to run all the wires through to the Switches.
5. Insert all switches and circuit breakers into the Switch Panel Box. Switches are installed into the panel from the front, and the Circuit Breakers are installed from the back.
6. Using connectors supplied, wire each switch to the accessory it will control. (See wiring diagram on back). The use of 12 Gauge wire is recommended. Remember to run the wires through the grommets before connecting.
7. When all connections are finished, secure the Switch Panel Box to Back Panel with the two DZUS Buttons.
8. Apply accessory label under each switch and re-connect the battery.

*For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 8:30am – 5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • P.O. Box 1470 • GUILFORD, CT 06437
Phone: (203) 453-6571 • FAX (203) 453-6906

Visit Us At www.moroso.com

74190INST

Rev.A
053000



SWITCH PANEL P/N 74190

PARTS

1 – Switch Panel Box	1 – Momentary Switch	2 – DZUS Buttons
1 – Back Panel	5 – ON/OFF Switches	27 – Connector
2 – Plastic Grommets	5 – Circuit Breakers	1 – Label Sheet

INSTALLATION INSTRUCTIONS

1. Disconnect battery before beginning installation.
2. Prepare a location on the roll bar to weld the Back Panel. Leave enough room for the Switch Panel Box.
3. After you have finished preparing the mounting area, fit the Back Panel on the roll bar and weld it in place from the inside of the panel. (See diagram on back)
4. Insert the two Plastic Grommets into the holes of the Back Panel. These holes will be used to run all the wires through to the Switches.
5. Insert all switches and circuit breakers into the Switch Panel Box. Switches are installed into the panel from the front, and the Circuit Breakers are installed from the back.
6. Using connectors supplied, wire each switch to the accessory it will control. (See wiring diagram on back). The use of 12 Gauge wire is recommended. Remember to run the wires through the grommets before connecting.
7. When all connections are finished, secure the Switch Panel Box to Back Panel with the two DZUS Buttons.
8. Apply accessory label under each switch and re-connect the battery.

*For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 8:30am – 5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • P.O. Box 1470 • GUILFORD, CT 06437
Phone: (203) 453-6571 • FAX (203) 453-6906

Visit Us At www.moroso.com

74190INST

Rev.A
053000

